

AKKAR® Model 312

Triple Barrel Shotgun Part List

STOCK GROUP

- 1 Recoil Pad Screw(x2)
- 2a Recoil Pad
- 2b Recoil Pad Base
- 3 Stock
- 4 Stock Bolt
- 5 Stock Bolt Lock Washer
- 6 Stock Bolt Washer

RECEIVER GROUP

- 7 Receiver
- 8 Top Lever
- 9 Top Lever Locking Spring
- 10 Top Lever Locking Pin
- 11 Top Lever Retainig Pin
- 12 Top Lever Spring
- 13 Top Lever Spring Guide
- 14 Top Lever Pin
- 15 Locking Plate
- 16 Safety
- 17 Safety Spring
- 18 Safety Spring Pin
- 19 Safety Spring Screw
- 20 Firing Pin Right
- 21 Firing Pin Left
- 22 Firing Pin Top

- 23 Firing Pin Retainer (2)
- 24 Firing Pin Spring (x3)
- 25 Hammer Cocking Rod
- 26 Sear (x3)
- 27 Sear Pin
- 28 Sear Spring (x3)
- 29 Trigger
- 30 Trigger Pin
- 31 Trigger Spring
- 32 Trigger Sear Catch
- 33 Trigger Sear Catch Pin
- 34 Trigger Sear Catch Plunger
- 35 Hammer Cocking Cam
- 36 Hammer Cocking Cam Spring
- 37 Hammer Cocking Cam Pin
- 38 Hammer Right
- 39 Hammer Left
- 40 Hammer Top
- 41 Hammer Spring Guide Rod (x3)
- 42 Hammer Spring (x3)
- 43 Hammer Pin
- 44 Bottom Plate
- 45 Bottom Plate Screw
- 46 Receiver Main Pin
- 47 Receiver Main Pin Stop Screw
- 48 Trigger Guard
- 49 Trigger Guard Pin

BARREL GROUP

- 50 Barrel Assembly
- 51 Extractor
- 52 Extractor Stop Screw
- 53 Front Sight
- 54 Choke Tube (x3)

FOREND GROUP

- 55 Forend
- 56 Iron Hook
- 57 Iron Hook Screw
- 58 Forend Screw Front
- 59 Lever Plate
- 60 Lever Plate Lug
- 61 Forend Plate Screw
- 62 Lever Plate Bushing
- 63 Lever Plate Bushing Screw
- 64 Forend Plate
- 65 Forend Catch Spring
- 66 Forend Catch
- 67 Forend Catch Pin